



7



9







10

ARES AR5

- PL** Instrukcja montażu
- GB** Assembly instructions
- ES** Instrucciones de instalación
- FR** Instructions de montage
- CZ** Montážní návod
- D** Montageanleitung
- HU** Összeszerelési útmutató
- SK** Montážny návod
- RU** Инструкции по монтажу
- IT** Istruzioni di montaggio
- RO** Instrucțiuni de asamblare
- TR** Montaj talimatı
- NL** Handleiding voor de montage
- UA** Інструкція монтажу

➔ ↑ ↗
1500x850x400



1	798x100x16
2	798x380x16
3	245x360x16
4	460x82x16
5	798x360x16
6	909x340x16
7	798x380x16
8	1501x400x16
9	1501x400x16
10	1482x406x2,5
11	462x590x16
12	462x170x16
13	445x390x4
14	462x170x16
15	462x170x16
16	452x390x4
17	462x170x16
18	340x114x16
19	418x100x16
20	340x114x16
21	418x100x16
22	339x435x2,5
23	462x170x16
24	1482x406x2,5

2x Z4	8x Z7	1x WL	1x WR	1x PL	1x PR	2x Z6	1x D4 ø5x50 mm
32x 4x16 A3	2x Z3	2x W2	4x 6x13 A1	12x P3	4x F5*16 B2	1x ø8 x50 mm D1	1x K4
30x 8x30 K1	23x #29,5 T1	23x F15mm M1	22x 3x16 A2	16x B5	4x Z5	1x ø43/1	1x ø43/6
10x 6,4x50 K3	6x N1	4x B1	12x 3,5x16 A4	2x Z5	2x W4	1x Z1	12x 4x20 A8

